d&b 5DM Firmware Release notes

An amplifier firmware update is performed using the d&b R1 Remote control software. To do this, start R1, navigate to the Service view, select the Firmware tab and download the latest version.

Updating the amplifier firmware requires an Ethernet connection to R1. In this case, make sure the network does not get interrupted during the process. An interruption during the update process does not harm the amplifier, just restart R1 and repeat the update.

Updating the amplifier firmware will factory reset the configuration.

5.0.9

Initial release.

Known issues:

- A change of the gPTP grandmaster during runtime may result in audible artifacts.
- Milan audio may be temporarily interrupted after startup or after a network cable is connected.

24 November 2026

5.0.8 and lower

Firmware used for early (pre-)series production.
This firmware is not Milan certified.

September 2026

(11/2026) © d&b audiotechnik GmbH & Co. KG

Loudspeaker setups

Setup	D40	40D	30D	10D	5D(M)	D80	D20
10A Arc	X	X	X	X	X	X	X
10A Lin	X	X	X	X	X	X	X
10ADArc	X	X	X	X	X	X	X
10ADLin	X	X	X	X	X	X	X
10S/A	X	X	X	X	X	X	X
10S/A-D	X	X	X	X	X	X	X
12S	X	X	X	X		X	X
12S-D	X	X	X	X		X	X
12S-SUB	X	X	X	X	X	X	X
16C	X	X	X	X	X	X	X
18S-SUB	X	X	X	X		X	X
21S-SUB	X	X	X			X	X
24C	X	X	X	X	X	X	X
24C-E	X	X	X	X	X	X	X
24S	X	X	X			X	X
24S-D	X	X	X			X	X
27S-SUB	X	X	X	X		X	X
44S	X	X	X	X	X	X	X
4S	X	X	X	X	X	X	X
5S	X	X	X	X	X	X	X
8S	X	X	X	X	X	X	X
AL60 PS	X	X	X			X	X
AL60 Out	X	X	X			X	X
AL60 In	X	X	X			X	X
AL60 AP	X	X	X			X	X
AL90 PS	X	X	X			X	X
AL90 Out	X	X	X			X	X
AL90 In	X	X	X			X	X
AL90 AP	X	X	X			X	X
B1-SUB	X	X	X			X	X
B2-SUB	X	X	X			X	X
B22-SUB	X	X	X			X	X
B4-SUB	X	X	X	X		X	X
B6-INF	X	X	X	X		X	X
B6-SUB	X	X	X	X		X	X
B8-SUB	X	X	X	X	X	X	X
C3	X	X	X			X	X

Setup	D40	40D	30D	10D	5D(M)	D80	D20
C4-SUB	X	X	X	X		X	X
C4-TOP	X	X	X	X		X	X
C6	X	X	X	X		X	X
C7-SUB	X	X	X	X		X	X
C7-TOP	X	X	X	X		X	X
Ci45	X	X	X	X		X	X
Ci60	X	X	X	X		X	X
Ci80	X	X	X	X		X	X
Ci90	X	X	X	X		X	X
E0	X	X	X	X	X	X	X
E12	X	X	X	X		X	X
E12-D	X	X	X	X		X	X
E12-DX	X	X	X	X		X	X
E12-SUB	X	X	X	X	X	X	X
E12-X	X	X	X	X		X	X
E15-SUB	X	X	X	X	X	X	X
E18-SUB	X	X	X	X		X	X
E3	X	X	X	X	X	X	X
E4	X	X	X	X	X	X	X
E5	X	X	X	X	X	X	X
E6	X	X	X	X	X	X	X
E8	X	X	X	X	X	X	X
E8-X	X	X	X	X		X	X
E9	X	X	X	X		X	X
F1220	X	X	X			X	X
F1222	X	X	X			X	X
GSL12 AP						X	
GSL12 Arc						X	
GSL12 Line						X	
GSL8 AP						X	
GSL8 Arc						X	
GSL8 Line						X	
J-INFRA			X			X	
J-SUB			X			X	
J-SUB AP			X			X	
J12 AP			X			X	
J12 Arc			X			X	
J12 Line			X			X	
J8 AP			X			X	

Setup	D40	40D	30D	10D	5D(M)	D80	D20
J8 Arc			X			X	
J8 Line			X			X	
KSL-SUB	X	X				X	
KSL-SUB Fln	X	X				X	
KSL-SUB AP	X	X				X	
KSL12 AP	X	X				X	
KSL12 Arc	X	X				X	
KSL12 Line	X	X				X	
KSL8 AP	X	X				X	
KSL8 Arc	X	X				X	
KSL8 Line	X	X				X	
Linear	X	X	X	X	X	X	X
M2			X			X	
M4 active	X	X	X	X		X	X
M4 passive	X	X	X	X		X	X
M6 active	X	X	X	X		X	X
M6 passive	X	X	X	X		X	X
MAX active	X	X	X	X		X	X
MAX passive	X	X	X	X		X	X
MAX2	X	X	X	X		X	X
Q-SUB	X	X	X	X		X	X
Q1	X	X	X	X		X	X
Q1-Line	X	X	X	X		X	X
Q10	X	X	X	X		X	X
Q7	X	X	X	X		X	X
SL-SUB						X	
SL-SUB AP						X	
T-SUB	X	X	X	X	X	X	X
T-SUB AP	X	X	X	X		X	X
T10 Arc	X	X	X	X	X	X	X
T10 Line	X	X	X	X	X	X	X
T10 AP	X	X	X	X		X	X
T10 PS	X	X	X	X	X	X	X
V-SUB	X	X	X			X	X
V-SUB AP	X	X	X			X	X
V10P	X	X	X			X	X
V12 Arc	X	X	X			X	X
V12 Line	X	X	X			X	X

Setup	D40	40D	30D	10D	5D(M)	D80	D20
V12 AP	X	X	X			X	X
V7P	X	X	X			X	X
V8 Arc	X	X	X			X	X
V8 Line	X	X	X			X	X
V8 AP	X	X	X			X	X
XSL12 AP	X	X	X			X	
XSL12 Arc	X	X	X			X	
XSL12 Line	X	X	X			X	
XSL8 AP	X	X	X			X	
XSL8 Arc	X	X	X			X	
XSL8 Line	X	X	X			X	
XSL-SUB	X	X	X			X	
XSL-SUB Fln	X	X	X			X	
XSL-SUB AP	X	X	X			X	
Y-SUB	X	X	X	X		X	X
Y-SUB AP	X	X	X	X		X	X
Y10P	X	X	X	X		X	X
Y12 Arc	X	X	X	X		X	X
Y12 Line	X	X	X	X		X	X
Y12 AP	X	X	X	X		X	X
Y7P	X	X	X	X		X	X
Y8 Arc	X	X	X	X		X	X
Y8 Line	X	X	X	X		X	X
Y8 AP	X	X	X	X		X	X